User Manual

Samsung Rugby Pro AdvanceCommunicator™

Part # ATT3001A

The AdvanceTec AdvanceCommunicator™ is designed to adapt the Samsung Rugby Pro into a Desktop Communications Base Station device.

Rev A 0715

INDEX

Page **Details**

2 – 3…….. Setting up the AdvanceCommunicator™

3 ……. Inserting into/removing phone from cradle

3 - 4 ……. Making and receiving calls in Hands-free mode

4 ……. Making and receiving call via Handset

4 ……. Use of AdvanceCommunicator™ with dispatch calls

4 ……. Volume control

4 ……..Recording of calls

5 ……. Summary of LED indicators

5 ……Charging of the battery

OPTIONAL ACCESSORIES

5 – 6 ……..Palm Mic. Part # ATT8428A

6 ……. Head Set Part # ATT8421A

7 ……Y-Connector Part # ATT8405A

8 ……. Foot Pedal Part # ATT8400A

Setting up the AdvanceCommunicator™

1. Place the AdvanceCommunicator™ in a convenient position within easy reach of an AC power outlet.
2. Attach the plug at the end of the coil cord of the handset into the corresponding RJ45 handset receptacle on the back of the AdvanceCommunicator™.
3. Plug the power supply into the wall power outlet and the round barrel plug at the end of the cord of the power supply into the corresponding power receptacle on the back of the AdvanceCommunicator™
4. At this point the LED will flash RED

Installing the Cable to connect the phone to the AdvanceCommunicator™

1. Remove the rubber protective cover from the connector receptacle covering the micro USB connector on the BOTTOM of the handset (handset facing you) and insert the USB connector at the end of the one cable into the phone with the cable connector facing to the LEFT.
2. Remove the rubber protective cover from the connector receptacle covering the audio connector on the TOP of the handset (handset facing you) and insert the straight audio pin connector at the end of the other cable into the handset.
3. Insert the 2 pin connector into the receptacle below the rim on the left side of the AdvanceCommunicator.

Inserting into/removing the phone from cradle

1. Insert the bottom of the phone behind the ridge on the cradle and press the top of the phone back into the Cradle until it snaps securely into place.

2. To remove the handset from the Cradle, press the release button on the top of the cradle. The Handset will snap forward allowing the phone to be removed out of the cradle.

Making and Receiving calls in Hands Free Mode.

1. Turn on the phone.
2. To make a call in Hands-free mode, dial the desired number on the phone keypad and press SEND/GREEN BUTTON. Speak towards the Microphone situated on the bottom right corner of the AdvanceCommunicator™
3. The voice of the person you are calling will be heard via the built-in speaker in the AdvanceCommunicator™
4. To receive a call in Hands-free mode, press the SEND/GREEN Button on the phone or press briefly on the EPTT/Space bar and speak towards the Microphone. The caller's voice will be heard via the built-in speaker in the AdvanceCommunicator™
5. To end a call in hands-free mode press the END/RED button on the phone.

Making and Receiving calls via the Handset.

1. To make a call using the AdvanceCommunicator™ Handset, dial the desired number on the phone's keypad and press the SEND/GREEN button. Use the handset as you would with a regular desktop phone.
2. To receive a call with the Handset, lift the Handset and press the SEND/GREEN button on the phone's keypad. Use the handset as you would with a regular desktop phone.
3. To end a call while using the handset, place the handset back into the cradle and press the END/RED button on the phone.

Use of the AdvanceCommunicator™ with Dispatch calls

1. To respond to a dispatch call in Hands-free mode, press and hold down the EPTT/Space Bar and speak towards the Microphone.
2. To respond to a dispatch call using the handset, pick up the handset, press and hold down the round EPTT button on the back of the Handset and speak into the handset as you would with a regular desktop phone.
3. To hear the other party in a dispatch call, release the EPTT/Space bar (in Hands-free mode) or the round EPTT handset button if using the Handset

Volume Control

The volume of the AdvanceCommunicator™ can be increased or lowered with the volume buttons of the phone.

Recording of cellular and dispatch calls

1. The AdvanceCommunicator™ will allow the recording of audio traffic with an external recording device via a 3.5mm plug on the back of the AdvanceCommunicator™.

- Dispatch calls will be recorded both audio in and audio out.
- Cellular calls will be recorded audio-in **ONLY.**

Summary of LED Indicators

Flashing RED:	Phone not connected to the Base
Steady RED:	Phone is connected to the Base with power OFF
Steady GREEN:	Phone connected with power ON

Charging the battery

With the phone turned off, the AdvanceCommunicator™ will charge the battery to 60% in approximately 1 hour. The charge time will be longer if the portable is operational during charge time.

NOTE: Batteries of the phone will charge within the temperature window of -10 C to +40 C (50 F to 104 F). If the battery is outside this temperature window, no charge current will be supplied to the battery.

Optional Accessories

The following optional accessories are available to compliment the AdvanceCommunicator™:

1. Palm Mic. - Part # ATT8428A

1. To use a Palm Mic. with the AdvanceCommunicator™ unplug the privacy handset supplied with the unit (and remove it from its cradle) and plug the RJ45 connector of the Palm Mic into the corresponding RJ45 receptacle on back of the AdvanceCommunicator™
2. Once connected, the pressing of the switch on the Palm Mic. will activate the Palm Mic.

2. Headset - Part # ATT8421A

1. To use the Headset with the AdvanceCommunicator™ unplug the privacy handset supplied with the unit (and remove it from its cradle) and plug the RJ45 connector of the Headset into the corresponding RJ45 receptacle on back of the AdvanceCommunicator™
2. Once connected, audio will be transferred to the Headset.
3. PTT calls can be made with the PTT/Space Bar or the PTT button on the cable on the Headset.

3. Foot Pedal - Part # ATT 8400A (with Part # ATT8405A)

1. To use the Foot Pedal with the AdvanceCommunicator™ unplug the privacy handset supplied with the unit (and remove it from its cradle)
2. Plug the RJ45 connector of the Y Adapter Cable (Part # AT8405A supplied) into the corresponding RJ45 receptacle on back of the AdvanceCommunicator™

3. Plug the RJ45 connector of the Foot pedal into one of the corresponding RJ45 receptacle of the Y Adapter Cable AT8405A.

4. To use both the Headset and Foot Pedal with the AdvanceCommunicator™ simultaneously, use the Y connector adapter Part # ATT8504A supplied with the Foot Pedal..
5. Unplug the privacy handset supplied with the unit (and remove it from its cradle) and plug the RJ45 connector of the Y Adapter Cable into the corresponding RJ45 receptacle on back of the AdvanceCommunicator™
6. Plug the Headset and Foot Pedal into the corresponding RJ45 receptacles of the Y Adapter Connector.
NOTE: If neither the headset nor Foot Pedal work, swap around the plugs into the Y Adapter Connector.
7. Once connected, the Headset and Foot Pedal will function as set out above.

ADVANCETEC INDUSTRIES INC
1150 NW 163rd Drive, Miami, FL 33169
T: 305-623-3939 F: 305-623-3996
Toll free USA 1-800-881-8211
www.advancetec.com
www.advancemobileGPS.com